Keychron K12 cheat sheet

Fn1 key

1 + Esc	Symbol `
Fn1 + 1	Screen Brightness Down
Fn1 + 2	Screen Brightness Up
Fn1 + 3	Launches Mission Control
Fn1 + 4	Launchpad
Fn1 + 5	Keyboard Backlight Down
Fn1 + 6	Keyboard Backlight Up
Fn1 + 7	Rewind
Fn1 + 8	Play / Pause
Fn1 + 9	Fast Forward
Fn1 + 0	Sound: Volume Mute
Fn1 + -	Sound: Volume Down
Fn1 + =	Sound: Volume Up
Fn1 + Backspace	Change Backlight Effects
Fn1 + Q	Select Bluetooth device #1
Fn1 + W	Select Bluetooth device #2
Fn1 + E	Select Bluetooth device #3
Fn1 + Q	(long press for 3s) Pair with Bluetooth device #1
Fn1 + W	(long press for 3s) Pair with Bluetooth device #2
Fn1 + E	(long press for 3s) Pair with Bluetooth device #3
Fn1 + I	Menu (Only works in Windows mode □
Fn1 + O	Scroll Lock
Fn1 + P	Insert
Fn1 + [Page Up
Fn1 +]	Home
Fn1 + ;	Page Down
Fn1 + '	End
Fn1 + L	Screen Shot
Fn1 + K	Arrow Up
Fn1 + M	Arrow Left
Fn1 + ,	Arrow Down
Fn1 + .	Arrow Right
Fn1 + /	Delete

fn2 key

Fn2 + Esc	Symbol ~
Fn2 + 1	F1
Fn2 + 2	F2
Fn2 + 3	F3
Fn2 + 4	F4
Fn2 + 5	F5
Fn2 + 6	F6
Fn2 + 7	F7
Fn2 + 8	F8
Fn2 + 9	F9
Fn2 + 0	F10
Fn2 + -	F11
Fn2 + =	F12
Fn2 + Backspace	Turn On / Off the Backlight
Fn2 + or Fn2 +	Change The Backlight Color

Misc.

Fn1 + B	Check Battery (Still in Beta, not 100% accurate□
Fn1 + B	RGB-Backlight Version: Backlight Red = 0~30% Power, Backlight Blue = 30%~70% Power, Backlight Green = 70%~100% Power
Fn1 + B	White-Backlight Version: Two Rows Backlight off & the Other On = 0~30% Power, One Row Backlight off & the Other On= 30%~70% Power, All Backlight On = 70%~100% Power
Fn1 + B	Non-Backlight Version: Q Backlight Red= 0~30% Power, Q W Backlight Red = 30%~70% Power, Q W E Backlight Red = 70%~100% Power
Fn2 + L + Enter	(long press for 3s) Lock / Unlock the Backlight Effect
Fn2 + M or Fn2 + .	Change the Backlight Color
Fn2 + S + L + O	(Bluetooth mode, long press for 3s) Disable the Auto Sleep Mode

Fn2 + S + L + T	(Bluetooth mode, long press for 3s) Auto Sleep in 20 Minutes Without Typing
Fn2 + S + L + Y	(Bluetooth mode, long press for 3s) Auto Sleep in 30 Minutes Without Typing
Fn1 + Win	(Windows mode, long press for 3s) Lock / Unlock the Keyboard (Only works in Windows mode)
Fn1 + J + Z	(long press for 3s) Reset the Keyboard

Source: keychron.com

Last modification: 7/17/2022 4:10:16 PM

More information: defkey.com/keychron-k12-

shortcuts

Customize this PDF...