

Arteck keyboard cheat sheet

General

[Customize this PDF...](#)

F12	(in iOS and Android mode) Show power meter
-----	--

Fn + F12 (Windows mode) Show power meter

Blinking 1 time means the battery is around 25%;
 blinking 2 times means the battery is around 50%,
 blinking 3 times means the battery is 75%, blinking 4 times means the battery is full.

Bluetooth1 or Bluetooth2 or Bluetooth3	(long press) Pairing
--	----------------------

Bluetooth1 or (short press) Switch
 Bluetooth2 or
 Bluetooth3

Pairing steps

Step 1: On the keyboard. slide the power button on.
 The blue power light will illuminate for 4 seconds and then turn off to save power. Your keyboard is still on.

Step 2: Long press the G for 3 seconds till you see 01 light is blinking.

Step 3: On your 1st device. select: Settling > Bluetooth > On.

Step 4: Your 1st device will display "Bluetooth 3.0 keyboard" as an available device.

Step 5: Select "bluetooth 3.0 keyboard" on the 1st device, the keyboard is paired to your 1st device now.

Step 6: Press Fn+Q if your 1st device is iOS: press Fn+W if your.1st device is Anroid; press Fn+E if your 1st device is Windows.

Note: If you skip the step 6, Windows may not use F1 - F12 and Esc key properly. If this is the case, press Fn + E to set your operating system as Windows.

Function keys

F7	Turn on the Fn lock
----	---------------------

Fn + F6 Turn off the Fn lock

Source: HB220b Arteck Keyboard manual

Last modification: 3/24/2022 4:12:00 PM

More information: defkey.com/arteck-HB220b-shortcuts