



Geek GK61 cheat sheet

General

Fn + Win	Block / Unblock Windows key
Fn then Fn	Toggle permanent Fn mode
Fn + [1 - 9]	F1 to F10
Fn + -	F11
Fn + =	F12
Fn + Backspace	No lighting
Fn + P or Fn + [Adjust brightness
Fn +]	Logic lights
Fn + \	Code lights
Fn + Q	Online mode
Fn + W or Fn + E or Fn + R	Macro settings

For useful information regarding GK61, take a look at this [Reddit](#) topic.

Last modification: 20.11.2020 14:05:45

More information: defkey.com/be/geek-gk61-gk64-shortcuts

[Customize this PDF...](#)