

HX Edit (Windows) cheat sheet

Global

Tab	Window focus (forward)
Shift + Tab	Window focus (reverse)
T	Enter tap tempo
Shift + T	Tap tempo mode selection
F1	HX Edit Pilot's Guide
Alt + /	About box window

File menu

Ctrl + S	Save preset
Ctrl + Shift + S	Save preset as
Ctrl + I	Import preset/IR/Favorite
Ctrl + E	Export preset/IR/Favorite
Ctrl + Alt + I	Import setlist
Ctrl + Alt + E	Export setlist
Ctrl + Shift + I	Import bundle (Helix devices)
Ctrl + Shift + E	Export bundle (Helix devices)
Alt + Enter	Preferences
Ctrl + Q	Quit

Edit menu

Ctrl + C	Copy
Ctrl + V	Paste
Del	Clear
Ctrl + A	Select all
Ctrl + R	Rename

Window menu

Ctrl + Shift + L	Show/Hide Librarian panel
Ctrl + Shift + M	Command Center
Ctrl + Shift + G	Global EQ (Helix & Stomp devices)

Snapshots menu

Ctrl + Shift + C	Copy
Ctrl + Shift + V	Paste
Ctrl + Shift + R	Rename
Ctrl + Shift + 1	Snapshot 1 (All Helix & HX devices)

Devices menu

Alt + 0	Select device's HX Edit window
---------	--------------------------------

Librarian window

P	Presets tab
I	IRs tab
F	Favorites tab
Right click or Shift + Enter	Display context menu
Left arrow / Right arrow	Change tab focus
Up arrow / Down arrow	Navigate selection
Shift + Up arrow / Down arrow	Extend selection
Shift + Left click	Contiguous multi-select
Ctrl + Left click	Non-contiguous multi-select
Left click	(delay click) Rename preset/IR
R	Rename setlist (Helix devices)
1	Setlist 1 (Helix devices)
2	Setlist 2 (Helix devices)
3	Setlist 3 (Helix devices)
4	Setlist 4 (Helix devices)
5	Setlist 5 (Helix devices)
6	Setlist 6 (Helix devices)
7	Setlist 7 (Helix devices)
8	Setlist 8 (Helix devices)
Ctrl + Left click + Move the mouse	(dragging presets) Copy into new preset slot location, overwrite presets currently exists there

Signal flow

Arrow keys	Navigate selection
Enter	Exit tab
Shift + Enter or Right click	Display block context menu
Space	Block bypass toggle
A	Amp block select (Helix & HX effects devices)
Left click	Block select

Double click	Display Edit tab - Modal browser
--------------	----------------------------------

In context menus, use arrow keys to navigate, press Enter to make a selection, Esc to close to menu.

Inspector window

E or H	Edit tab
B or C	Bypass/Controller assign tab
Left arrow / Right arrow	Select previous/next parameter or list
Shift + Left arrow / Right arrow	Select previous/next tabbed list
Alt + Left click	Snapshot assign
Shift + Enter or Right click	Display context menu
Ctrl + Left click	Reset to default
G	Toggle model list and grid views

Edit tab: Category list or Model/Grid list focus

Up arrow / Down arrow	Change category or model selection
Left arrow / Right arrow	Move focus between category list, model list, and parameter sliders

Note: If Model Grid is visible, Shift key must be used to advance the focus out of Model Grid)

Shift + Right arrow	(when Model Grid View is in use) Move focus to the first parameter slider
Shift + Left arrow	(when Model Grid View is in use) Display the Model Category menu

Use up and down arrow keys to navigate, Enter to select in the menu.

G	Toggle between displaying the Category/Model List View and Model Grid View
Shift + D	Select Distortion category
Shift + Y	Select Dynamics category
Shift + Q	Select EQ category
Shift + M	Select Modulation category
Shift + L	Select Delay category

Shift + R	Select Reverb category
Shift + S	Select Pitch/Synth category
Shift + F	Select Filter category
Shift + W	Select Wah category
Alt + Shift + A	Select Amp+Cab category (Helix and HX Stomp devices)
Shift + A	Select Amp category (Helix and HX Stomp devices)
Shift + P	Select Preamp category (Helix and HX Stomp devices)
Shift + C	Select Cab category (Helix and Stomp devices)
Shift + I	Select IR category
Shift + V	Select Volume/Pan category
Shift + N	Select Send/Return category
Shift + O	Select Looper category

Edit tab: Parameter Slider Focus

Up arrow / Down arrow or = or -	Increment/decrement parameter value - fine adjustment
Shift + Up arrow / Down arrow or Shift + = or Shift + -	Increment/decrement parameter value - coarse adjustment
Enter	Edit numerical parameter value or show drop-down menu for discrete parameter choices

In the menu, use up / down arrow keys to navigate, and Enter to make selection. Use Esc key to dismiss the menu.

Shift + Enter	Open the selected slider's context menu for controller assignment options
N	For "Note Sync" capable parameters, this toggles the functionality between Note Sync and ms/Hz
D	Return the parameter value to its default value
S	For block parameters, assigns parameter to a Snapshot controller
Double click	Enter edit mode for numerical parameter value (press Enter to

	accept edited value)
--	----------------------

Command Center, Global EQ & Preferences Window

(Helix and HX Effects devices only) Focus within these windows is indicated by the turquoise-colored outline surrounding a control, or by the vertical line at the left of any parameter slider.

Any control has focus:

Shift + Ctrl + M	Open and move the Command Center window to the foreground
------------------	---

When the Command Center window has focus, you can close it using Alt + F4.

Tab	Move focus to next command parameter
-----	--------------------------------------

Shift + Tab	Move focus to previous command parameter
-------------	--

Parameter slider focus:

Up arrow / Down arrow or = or -	Adjust the selected parameter slider's value up or down using small increments
---------------------------------	--

Shift + Up arrow / Down arrow or = or -	Adjust the selected parameter slider's value up or down using large increments
---	--

Enter	Edit numerical parameter value
-------	--------------------------------

Customize label control focus:

Enter	Edit custom label
-------	-------------------

Del	Remove custom label
-----	---------------------

Controller grid focus:

Arrow keys	Select controller within grid
------------	-------------------------------

Command Menu focus:

Arrow keys or = or -	Command menu option selection
----------------------	-------------------------------

Command Center window

Enter	Open Command menu
-------	-------------------

Esc	Dismiss Command menu
-----	----------------------

Up arrow / Down arrow	Change Command menu selection
-----------------------	-------------------------------

Global EQ window

Any control has focus:

Shift + Ctrl + G	Open Global EQ window
------------------	-----------------------

Tab	Focus next
-----	------------

Shift + Tab	Focus previous
-------------	----------------

R	Reset
---	-------

A	Apply EQ (Helix devices)
---	--------------------------

B	Bypass
---	--------

EQ Graph Pane focus:

1	Select the Low Cut mode
---	-------------------------

2	Select the Low Peak mode
---	--------------------------

3	Select the Mid Peak mode
---	--------------------------

4	Select the High Peak mode
---	---------------------------

5	Select the High Cut mode
---	--------------------------

Arrow keys	Adjust edit node - Fine
------------	-------------------------

Shift + Arrow keys	Adjust edit node - Coarse
--------------------	---------------------------

Q	Increment Q Value - Fine
---	--------------------------

Shift + Q	Increment Q Value - Coarse
-----------	----------------------------

Ctrl + Q	Decrement Q Value - Fine
----------	--------------------------

Ctrl + Shift + Q	Decrement Q Value - Coarse
------------------	----------------------------

Control specific focus:

Enter	Reset
-------	-------

Space	Bypass
-------	--------

Enter	Close window
-------	--------------

Arrow keys or = or -	Apply to output options (helix devices)
----------------------	---

Preferences window

Alt + Enter	Open Preferences window
-------------	-------------------------

Last modification: 6.9.2023. 15:55:50

More information: defkey.com/bs/hx-edit-windows-shortcuts

[Customize this PDF...](#)