

Drop CTRL cheat sheet

LED keys

Fn + A	LED Pattern Select Previous
Fn + D	LED Pattern Select Next
Fn + W	LED Brightness Increase
Fn + S	LED Brightness Decrease
Fn + Q	LED Scrolling Pattern Speed Decrease
Fn + E	LED Scrolling Pattern Speed Increase
Fn + Tab	LED Toggle Breathe Effect
Fn + Caps Lock	LED Toggle Scrolling Pattern Direction
Fn + X	LED Toggle On/Off
Fn + Z	LED Toggle Mode (Keys + Edge, Keys Only, Edge Only, Only modifiers)

Media keys

Fn + Page Up	Volume Up
Fn + Page Down	Volume Down
Fn + Print	Mute
Fn + Insert	Play/Pause
Fn + Home	Stop
Fn + Del	Previous
Fn + End	Next

Keyboard option keys

Fn + N	Toggle keyboard 6KRO/NKRO (Default state 6KRO)
--------	--

Custom configuration

The shortcuts above was basic hotkeys for the keyboard. Drop CTRL allows you to create custom configurations on its Configurator page and compile the firmware with your own configuration. See [Source](#) link below for more information.

Source: [Drop.com](#)

Last modification: 3/5/2021 7:58:43 PM

More information: defkey.com/drop-ctrl-shortcuts

[Customize this PDF...](#)