

eMachineShop cheat sheet

General

1	Zoom 1:1
Shift + +	Zoom In
–	Zoom Out
= or +	Zoom to Fit
E	Selects Eraser Tool
/	Selects Line Drawing Tool
[Selects Rectangle Drawing Tool
O	Selects Circle Drawing Tool
A	Selects Arc Drawing Tool
T	Selects Text Drawing Tool
G	Selects Line Edit Tool
C	Selects Corner Rounding Tool when an applicable shape is selected.
G	Selects Line Edit Tool
V	Changes the view of the drawing
L	Rotates the selection to the left
R	Rotates the selection to the right
F1	Opens Help Guide in browser
F2	Opens Preferences dialog
F5	Opens the Line > Machine dialog
F9	Prices the current design
Tab	Changes selection to the next object
Shift + Tab	Changes selection to the previous object
Ctrl + D	Selects the Repeat Tool
Ctrl + G	Groups current selections
Ctrl + I	Initiates the Intersect function
Ctrl + J	Opens the Settings dialog
Ctrl + M	Opens the Materials dialog
Ctrl + R	Opens the 3D Render View of the drawing
Ctrl + T	Opens Rotations setting dialog
Ctrl + U	Ungroups current selection
Ctrl + F6	Opens the Contour dialog
Ctrl + Alt + F3	Request a Manual Quote
Ctrl + Shift + N	New Instance
Ctrl + Page Up	Goes to the top layer

Ctrl + Page Down Goes to the bottom layer

Page Up Go up a layer

Page Down Go down a layer

Source: emachineshop.com

Last modification: 11/6/2023 10:54:54 AM

More information: defkey.com/emachineshop-shortcuts

[Customize this PDF...](#)