



Avolites Titan 17.0 cheat sheet

Buttons

These are some of the physical key combinations you can use in Titan. For more information, please check the link in the source at the bottom of the article.

AVO + ALL	Set zero intensity into programmer for unselected fixtures (same as REM DIM), see Turn off unselected fixtures. Also used when setting Attribute Times to deselect all fixtures, see Attribute Fade Times.
AVO + BACK	Undo
AVO + CLOSE	Close all workspace windows, see Workspace windows.
AVO + COPY	Same as pressing MOVE (for consoles which don't have a Move button, but works on all consoles)
AVO + DISK	Enter System menu to set up the console, see System Menu.
AVO + EXIT	Exit menu structure back to the top level.
AVO + FixPlus	Jump the pattern forward (or back with FIX MINUS) in pattern select mode.
AVO + FLASH	ON Flash out (turn off) selected fixtures while held.
AVO + GROUP	{Select} Record group to handle, see Record a group.
AVO + HIGHLIGHT	Record the highlight state, see Highlight
AVO + MACRO	{Select} Record macro to handle, see Key Macro buttons.
AVO + MIN/MAX	Select a different workspace window to be the active window, see [Workspace windows](../titan-basics/workspace-windows).
AVO + OPEN/VIEW	{Workspace button} Record workspace layout, see Saving workspace layouts.
AVO + RELEASE	Release all playbacks by priority (same as double press RELEASE). See Release.
AVO +	Move the active workspace

SIZE/POSITION	window to the next screen, see Workspace windows.
AVO + TIME	Preview Attribute fade time, see Attribute Times.
AVO + UNDO or AVO + @	Redo
AVO + Blind	Toggle Blind mode, same as pressing BLIND.
AVO	hold and Edit current key profile: Reallocate the function of the Select and Flash buttons, see Key Profiles.
AVO + Lock	Temporarily lock console controls, see Locking the console.
AVO	hold and User Settings: Enter the User Settings menu, see User Settings.
AVO + {SceneMaster}	Enter or exit preset mode when Scene Master assigned to Macro/Executor button or touch button, see Scene Master.
AVO + {Master}	Releases the master to its default state (no effect on output), see Releasing a Master.
AVO + {Playback}	Kill playback, see Release.
AVO	and Turn wheel: Wheel Turbo mode, 1 revolution goes through entire attribute range
AVO + 2 or AVO + 4 or AVO + 6 or AVO + 8	Cursor up, left, right, down

Keyboard

These shortcuts are particularly useful when using Titan PC Suite (Titan Go or Titan Simulator).

F1	Open user manual
F2	Activate window
F3	Minimise/Maximise
Shift + F3	Next window
F4	Size/Position
Shift + F4	Move to other screen
F5	Close window
Shift + F5	Close all windows

F6	Open Playbacks window
F7	Open Fixtures window
F8	Open Groups window
F9	Open Colours window
F10	Open Positions window
F11	Gobos/Beams window
F12	Open Channel Grid
Esc	Exit menu
Enter	Enter
Alt + 1	Softkey A
Alt + 2	Softkey B
Alt + 3	Softkey C
Alt + 4	Softkey D
Alt + 5	Softkey E
Alt + 6	Softkey F
Alt + 7	Softkey G
Alt + Shift + F	Fixture
Alt + Shift + P	Palette
Alt + Shift + M	Macro
Alt + Shift + G	Group
Num /	Thro
Num *	@
Num -	Not
Num +	And
Alt + Left arrow	Previous fixture
Alt + Right arrow	Next fixture
Alt + Up arrow	All
Alt + Down arrow	Highlight
Ctrl + X	Cut text
Ctrl + C	Copy text
Ctrl + V	Paste text
Ctrl + A	Select all text
Ctrl + Z	Undo
Ctrl + Y	Redo
Alt + C	Clear
Alt + R	Record menu
Alt + A	Toggle Avo menu
Alt + L	Locate
Alt + P	Patch

Alt + Shift + D	Disk menu
Alt + Shift + S	System menu
Alt + V	Open/View menu
Alt + G	Go
Alt + D	Delete
Alt + Shift + C	Copy
Alt + M	Move
Alt + U	Unfold
Alt + I	Include
Alt + Shift + R	Release
Alt + S	Shape
Alt + Shift + T	Fixture Tools/ML Menu
Alt + B	Blind
Alt + O	Off
Alt + F	Fan
Alt + Shift + O	Attribute options
Alt + Shift + L	Latch menu
Alt + Q	Cue/Connect
Alt + W	Open Window
Alt + T	Times
Alt + Shift + U	Update
Alt + Shift + I	Select If

Sources: avolites.com (Button reference, Front panel buttons)

Last modification: 16/1/2024 15:52:10

More information: defkey.com/ha/avolites-titan-17-0-shortcuts

[Customize this PDF...](#)