

Jelly Comb foldable B003 and B047 cheat sheet

iOS and Android

Fn + `	Return to home
1	Search
2	Select
3	Copy
4	Paste
5	Cut
6	Previous track
7	Play / Pause
8	Next track
9	Mute
0	Volume decrease
-	Volume increase
=	Lock

Windows

Fn + `	Home
1	Search
2	Select
3	Copy
4	Paste
5	Cut
6	Previous track
7	Play / Pause
8	Next track
9	Mute
0	Volume decrease
-	Volume increase
=	Lock

B003 Touchpad functions

One finger click: Mouse left click

Two finger slide: Mouse wheel

Three finger slide up: Win + Tab shortcut

Two finger click: Mouse right click

Two finger stretch: Zoom

Three finger slide to the left or right side: Interface switch

Three finger slide down: Win + D shortcut (return to

Windows desktop)

B047 specific shortcuts: Language switching

Ctrl + Space	(for iOS) Switch physical keyboard input method
Shift + Space	(for Android) Switch physical keyboard input method
Win + Space	(for Windows) Switch physical keyboard input method

This feature will only work when more than one language input method is installed on the system.

Source: Jelly Comb B003 manual, B047 manual

Last modification: 11/27/2020 1:59:02 PM

More information: defkey.com/jelly-comb-b003-b047-shortcuts

[Customize this PDF...](#)