AKKO 3068 cheat sheet

General

Fn + [0 - 9]	F1 - F10
Fn + -	F11
Fn + =	F12
Fn + Page Up	Home
Fn + Page Down	End
Fn + I	Insert
Fn + P	Parts
Fn + C	Calculator
Fn + M	Mute
Fn + <	Decrease volume
Fn + >	Increase volume
Fn + W	Swap WASD with arrowkeys

System commands (Windows)

Fn + Win	Lock Windows
Fn + ~	(hold for 3 seconds) Restore factory settings
Fn + Right Ctrl	(hold for 3 seconds) Revert Ctrl into Menu (App) key
Fn + Q	(hold for 3 seconds) Enter Windows system
Fn + O	(hold for 3 seconds) Enter Mac system

System commands (Mac)

1	Decrease display brightness
2	Increases display brightness
3	Open mission control
4	Activate Siri
5	F5
6	F6
7	Skip back (Audio)
8	Pause/Play (Audio)
9	Skip forward (audio)
0	Mute
-	Volume down
+	Volume up
Right Alt	Command key

Win	Option key
Left Alt	Command key

Backlight settings

Fn + /In all lighting effects with RGB color mode, set the backlight color to 7 single colors with RGB loop effectFn + DelConstant / Breath / Neon / Wave / Ripple / Star / Effect A / Effect B / Effect C / Effect D / Effect E / Effect F / Effect G / Effect H / Effect I / Effect J / Effect N (20 Lighting Effects)Fn + LLighs on / offFn + [Slower animationFn + 1]Faster animationFn + Up arrowBrightFn + Left arrowSet animation direction to leftFn + Right arrowSet animation direction to right	-	-
 / Ripple / Star / Effect A / Effect B / Effect C / Effect D / Effect E / Effect F / Effect G / Effect H / Effect I / Effect J / Effect K / Effect L / Effect M / Effect N (20 Lighting Effects) Fn + L Lighs on / off Fn + [Slower animation Fn +] Faster animation Fn + Up arrow Bright Fn + Left arrow Set animation direction to left 	Fn + /	color mode, set the backlight color to 7 single colors with RGB
Fn + [Slower animationFn +]Faster animationFn + Up arrowBrightFn + Down arrowDimFn + Left arrowSet animation direction to left	Fn + Del	/ Ripple / Star / Effect A / Effect B / Effect C / Effect D / Effect E / Effect F / Effect G / Effect H / Effect I / Effect J / Effect K / Effect L/ Effect M / Effect N (20
Fn +]Faster animationFn + Up arrowBrightFn + Down arrowDimFn + Left arrowSet animation direction to left	Fn + L	Lighs on / off
Fn + Up arrowBrightFn + Down arrowDimFn + Left arrowSet animation direction to left	Fn + [Slower animation
Fn + Down arrowDimFn + Left arrowSet animation direction to left	Fn +]	Faster animation
Fn + Left arrow Set animation direction to left	Fn + Up arrow	Bright
	Fn + Down arrow	Dim
Fn + Right arrowSet animation direction to right	Fn + Left arrow	Set animation direction to left
	Fn + Right arrow	Set animation direction to right

Bluetooth feature

Fn + E	Bluetooth device 1: Short press to connect with slow flashing blue LED; Press and hold to pair
	device with fast flashing blue LED
Fn + R	Bluetooth device 2: Short press to connect with slow flashing blue LED; Press and hold to pair device with fast flashing blue LED
Fn + T	Bluetooth device 3: Short press to connect with slow flashing blue LED; Press and hold to pair device with fast flashing blue LED
Fn + Y	2.4G wireless device: Short press to connect with slow flashing green LED; The lighting effect will be restored when pairing succeeds
Fn + U	Wired mode: Short press to

connect with slow flashing green LED; The lighting effect will be restored when pairing succeeds

Setup instructions

1. When the keyboard remains unplugged, turn the back switch to ON. Then long press and hold Fn + E / R / T to start pairing with Bluetooth devices. The keyboard will enter Bluetooth pairing mode when the blue LEDs under E / R / T keys flash quickly.

2. When the Keyboard is plugged into the computer through USB interface, it will enter Bluetooth mode automatically without having to push the switch on the back. Users can directly long press and hold Fn + E / R / T to enable Bluetooth pairing. The keyboard will enter Bluetooth pairing mode when the blue LEDs under E / R / T keys flash quickly.

For more information about pairing, please refer to the manual (link below).

Source: AKKO 3068 manual

Last modification: 24-02-2025 09:31:14

More information: defkey.com/nl/akko-3068bluetooth-5-mechanical-shortcuts

Customize this PDF...