

Performance Base 65 cheat sheet

Keyboard modes & shortcuts

Fn + Esc	(Hold 5s) Reset keyboard and restore to factory settings
Fn + Win	Enable or disable the Windows key, Game mode
Fn + O	Insert key
Fn + P	Print Screen key
Fn + Page Up	Home key
Fn + Page Down	End key
Fn + F1	to F12: F1~F12 key
Fn + Left Ctrl	(Hold 2s) Enable or disable the F1-F12 function key lock

Activate = Keyboard flash white LED x2

Deactivate = Keyboard flash white LED x1

,	
Fn + Up arrow	Decrease lighting brightness (0-7 levels)
Fn + Down arrow	Increase lighting brightness (0-7 levels)
Fn + Left arrow	Decrease lighting speed (1-7 levels)
Fn + Right arrow	Increase lighting speed (1-7 levels)

Magnet Switch Sensitivity Adjustment

Fn + Enter	Enter Sensitivity Adjustment
	Mode

Sensitivity Adjustment:

~' key to select all keys or

Press any key to select custom keys

Del = Restore default value

PgUp = Sensitivity Increase

PgDn = Sensitivity Decrease

FN = Exit Sensitivity Adjustment Mode

Fn + Space	(hold 3s) Toggles through 3
	preset profiles below

Profile 1: Keyboard flash PURPLE LED x2

Preset Rapid Trigger = Medium (Step 9 - 1.6mm)

Profile 2: Keyboard flash YELLOW LED x2

Preset Rapid Trigger = Slow (Step 21 - 4.0mm)

Profile 3: Keyboard flash GREEN LED x2

Preset Rapid Trigger = Fast (Step 3 - 0.4mm)

Note: Sensitivity adjustments made to each of the profiles will be saved. To restore a specific profile to default, Enter sensitivity adjustment mode, (~) select all keys and then (Del) restore

Lighting Effects

Fn + Tab	Rotate lighting effects
Fn + C	Cycle colors to White, Red, Green, Blue, Yellow, Purple,
	Cyan

16 onboard effects: Lighting effect #1: Rightwave Lighting effect #2: Breathe Lighting effect #3: Radiance Lighting effect #4: Hitaoe Lighting effect #5: Radar Lighting effect #6: Crossline Lighting effect #7: Zen Lighting effect #8: Laser Lighting effect #9: Crosswave Lighting effect #10: Spectrum Lighting effect #11: Explosion Lighting effect #12: Silvasurfa Lighting effect #13: Higround Lighting effect #14: Tripple Lighting effect #15: BreatheRGB Lighting effect #16: Solid

Multimedia Functions

Fn + ,	Previous Track
Fn + M	Play/Pause
Fn + .	Skip Track
Fn + L	Sound Volume Up
Fn + K	Sound Volume Down
Fn + J	Sound Mute

Source: higround.co

Last modification: 2025/2/7 □ □ 9:04:38

More information: defkey.com/zh/performance-

base-65-higround-shortcuts

Customize this PDF...