

Avocent SwitchView KVM cheat sheet

Activating hotkeys

| | |
|--------------------------------|---------------------------|
| Scroll Lock then ScrollLock | Activates hotkey sequence |
|--------------------------------|---------------------------|

All SwitchView switches

| | |
|---|-----------|
| Scroll Lock then ScrollLock then 1 or Scroll Lock then ScrollLock then 2 or Scroll Lock then ScrollLock then 3 or Scroll Lock then ScrollLock then 4 | Select PC |
|---|-----------|

Press the Select button to select the next channel

| | |
|---|-----------------------------|
| Scroll Lock then ScrollLock then Up arrow / Down arrow | Next higher / lower channel |
|---|-----------------------------|

Press the Select button to toggle to the next channel

| | |
|---------------------------------------|---------------------|
| Scroll Lock then ScrollLock then B | Beep sound on / off |
|---------------------------------------|---------------------|

Scroll Lock then
Scroll Lock then S

Autoscan

SwitchView DVI, MM1 and MM2 Switches only

| | |
|--|--|
| Scroll Lock then ScrollLock then F1 | Switch KVM and USB Hub (no audio) - Port 1 |
| Scroll Lock then ScrollLock then F2 | Switch KVM and USB Hub (no audio) - Port 2 |
| Scroll Lock then ScrollLock then F3 | Switch KVM and USB Hub (no audio) - Port 3 |
| Scroll Lock then ScrollLock then F4 | Switch KVM and USB Hub (no audio) - Port 4 |
| Scroll Lock then ScrollLock then F5 | Switch KVM and Audio (no USB Hub) - Port 1 |
| Scroll Lock then ScrollLock then F6 | Switch KVM and Audio (no USB Hub) - Port 2 |
| Scroll Lock then ScrollLock then F7 | Switch KVM and Audio (no USB Hub) - Port 3 |
| Scroll Lock then ScrollLock then F8 | Switch KVM and Audio (no USB Hub) - Port 4 |
| Scroll Lock then | Bind PC and Hub Port Control |

ScrollLock then Z

Switching

Scroll Lock then

Unbind PC and Hub Port Control

ScrollLock then X

Switching

A note from the manual:

The default setting of the SwitchView MM1 USB KVM switch is appropriate for most systems. However, to utilize a USB keyboard/mouse, you may need to disable the PS/2 option in the BIOS and enable the USB option instead. In order for your PC to find your USB keyboard and mouse, you will need to sync your hub port control and PC port selection (for example, the green PC port LED and red USB hub port LED should be aligned). Also, USB keyboard users will NOT be able to utilize the SwitchView MM1 switch hotkey function.

Scroll Lock then

Bind PC and Audio / Mic

ScrollLock then Q

switching

Scroll Lock then

Unbind PC and Audio / Mic

ScrollLock then W

switching

Scroll Lock then

Autoscan with programmable

ScrollLock then S

delay time - 10 seconds

then 1

Scroll Lock then

Autoscan with programmable

ScrollLock then S

delay time - 20 seconds

then 2

Scroll Lock then

Autoscan with programmable

ScrollLock then S

delay time - 30 seconds

then 3

Scroll Lock then

Autoscan with programmable

ScrollLock then S

delay time - 40 seconds

then 4

Scroll Lock then

Autoscan with programmable

ScrollLock then S

delay time - 50 seconds

then 5

Scroll Lock then

Autoscan with programmable

ScrollLock then S

delay time - 60 seconds

then 6

Scroll Lock then

Toggle between previous

ScrollLock then

channel and current channel

Backspace

SwitchView DVI and MM2 Switches only

Scroll Lock then

then press Scroll Lock or Caps

ScrollLock then H

Lock or Esc or F12 or Num Lock:

Define hotkey preceeding

| | sequence |
|--|--|
| Scroll Lock then ScrollLock then S then 1 | Autoscan with programmable delay time - 10 seconds |
| Scroll Lock then ScrollLock then S then 2 | Autoscan with programmable delay time - 20 seconds |
| Scroll Lock then ScrollLock then S then 3 | Autoscan with programmable delay time - 30 seconds |
| Scroll Lock then ScrollLock then S then 4 | Autoscan with programmable delay time - 40 seconds |
| Scroll Lock then ScrollLock then S then 5 | Autoscan with programmable delay time - 50 seconds |
| Scroll Lock then ScrollLock then S then 6 | Autoscan with programmable delay time - 60 seconds |
| Scroll Lock then ScrollLock then S then 7 | Autoscan with programmable delay time - 70 seconds |
| Scroll Lock then ScrollLock then S then 8 | Autoscan with programmable delay time - 80 seconds |
| Scroll Lock then ScrollLock then S then 9 | Autoscan with programmable delay time - 90 seconds |
| Scroll Lock then ScrollLock then S then 10 | Autoscan with programmable delay time - 100 seconds |

SwitchView PC and MM1 Switches only

| | |
|--|-----------|
| Scroll Lock then ScrollLock then End | Reset KVM |
|--|-----------|

Source: SwitchView manual

Last modification: 1/20/2022 10:56:29 AM

More information: defkey.com/switchview-pc-dvi-mm1-mm2-kvm-shortcuts

[Customize this PDF...](#)