Redragon K580 RGB mechanical keyboard cheat sheet

General

Fn + Up arrow / Adjust key brightness

Down arrow

Macro recording

- 1. Press Rec to start recording. The four leds will flash simultaneously)
- 2. Press one of the five G keys and it lights up (G1~G5).
- 3. Press keys to be recorded.
- 4. Press Rec once again to save the recording. The Rec also will light up.

For example, to record 123 on G1: Rec \rightarrow G1 \rightarrow 123 \rightarrow Rec

Clear a recording

To clear a single recorded macro key: Press Rec+desired G key (G1-G5) you need to delete, then press Rec again. To delete all recorded macro keys(G1-G5): Press and hold Rec for 5 seconds, the light of Rec and G key goes off.

Two sides lighting

Fn + Pause Switch 5 lighting modes on two sides

Fn + Scroll Lock Adjust the lighting speed on two

sides

Source: Redragonzone.com

Last modification: 1/28/2022 3:20:26 PM

More information: defkey.com/redragon-k580-rgb-

shortcuts

Customize this PDF...